



Fuel Oil Pressure Booster

Plate  
4272-0500-0014

2013-02-04 - en

Item no	Qty	Designation
018	-	Union nut and plug screw
031	-	Sealing ring
055	-	Cone
067	-	Conical ring 2/2
079	-	Pressure spring
080	-	Housing
092	-	Spindle
102	-	Screw
114	-	Flange
126	-	Sealing ring
138	-	Throttle valve
151	-	Disc
163	-	Orifice plug, ext.thread
175	-	Packing
187	-	Screw
199	-	Screw
209	-	Top cover, complete
210	-	Guide pin
222	-	Sealing ring
234	-	Retaining ring for shaft
246	-	Hydraulic plunger
258	-	Sealing ring
271	-	Housing
283	-	Sealing ring
295	-	Screw
305	-	Inductive sensor
317	-	Sealing ring
329	-	Bushing
330	-	Sealing ring
342	-	Sealing ring
391	-	Plug screw
401	-	Disc
413	-	Screw
425	-	Pressure switch
437	-	Sealing ring
449	-	Non-return valve
450	-	Suction valve
462	-	Cap
474	-	Fuel oil booster plunger